




Tomahawk Live Trap llc.

TRAP SETTING INSTRUCTIONS



One Year
FACTORY WARRANTY

Mfg. Animal
Equipment Since
1925
www.livetraps.com

**PROUDLY
MADE IN THE USA**



Tomahawk Live Trap^{llc.}

We at Tomahawk Live Trap, would like to sincerely thank you for your purchase.

Everyone on our team works very hard to provide products that are safe, effective, and reliable. We take pride in our workmanship and we want you to have a positive experience with our products and service. To help you with your new Tomahawk Live Trap, our instruction sheet has detailed directions for setting and adjusting our traps. A 'QR' code is also provided which will take you to our video instruction pages on YouTube. Just use your smart phone to scan the cooresponding code which automatically takes you to our instruction videos for that product.

Please feel free to contact us with feedback regarding your new Tomahawk product or your experience with our customer service. We strive to improve, and your feedback is greatly appreciated and critical to help our team better serve you.

Sincerely,

Greg Smith



Mission statement: We aspire to exceed our customer's expectations by providing them with the highest quality humane animal control products available. We deliver our products as timely as possible, usually shipping same day. And our friendly, knowledgeable, professional staff will help inspire, educate and problem-solve for our customers so they can effectively use our products.

IMPORTANT, PLEASE READ!

Your trap may arrive with a plastic zip tie holding the trigger rod to prevent it from moving during shipping. Please cut and remove this zip tie for the trap to work properly.

DAMAGED MERCHANDISE

Immediately upon arrival, check your merchandise for any damage that may have occurred during shipping. Even if the box the merchandise was shipped in appears to be in perfect condition, open the box and inspect the merchandise for damage. Remember, the longer you wait to check your merchandise, the more difficult it becomes to file a claim with the shipper.

What to do if Your Merchandise is Damaged:

Ground Shipments: If your merchandise was shipped to you by a ground carrier such as FEDEX or UPS, please contact our Customer Service Office immediately at 715-356-4600. We will contact the shipper, report the damage, and file a claim. A representative may come out to your home or business to inspect the damaged item and original packaging.

Freight Line: If your merchandise was shipped to you by a Freight Line, sign for the merchandise as damaged. If you sign for the merchandise and do not inspect it until after the driver leaves, it will be too late to do anything regarding the damage. The Freight company will argue the damage occurred after the driver delivered the product. It is almost impossible to collect any damages if the shipment is signed for free and clear. So always inspect the shipment, and if there is damage, list the damage on the receipt the driver will give you to sign. It is also important that you contact our Customer Service Office at 715-356-4600 and report the damage.

RETURNED GOODS POLICY

There will be a 20% restocking charge and shipping charge on all returns unless the merchandise was defective, damaged in shipping, exchanged for other merchandise, or there was an error on our part in the processing of the order. You must contact our Customer Service Office at 715-356-4600 and supply us with the invoice number date of order and the reason for return. All returned merchandise must have order invoice number clearly written on the return label so that the merchandise may be properly identified and credited to your account. No future merchandise will be shipped until we have received the returned merchandise.

DELIVERIES THAT ARE REFUSED

Customers that refuse delivery of the merchandise will have the merchandise credited back to their account, minus the shipping cost of the merchandise, and a 20% handling and restocking charge.

MANUFACTURER'S PROCESSING ERROR

Should you have a problem with an order due to an error on our part, we will correct the problem at our expense. You will have 10 days from the day we shipped the merchandise to you, to contact our Customer Service Office at 715-356-4600, and request a return authorization number before returning the merchandise. You must supply us with the invoice number and date, as well as the reason for the return before any return authorization number can be given. All returned merchandise must have the return authorization number clearly written on the return label so that the merchandise may be properly identified and credited to your account. After we receive the returned merchandise, a replacement will be shipped to you entirely at our expense.

LATE PAYMENTS

All open accounts are billed Net 30 from the date the merchandise was shipped and invoiced. If payment is not received within 30 days, interest of 1½% per month will be applied to the balance, which is an annual percentage rate of 18%. All accounts must be paid in full, including interest, to maintain established credit.

Thanks again for your order. We are confident that you will be extremely pleased with the great value and quality of your new Tomahawk Live Trap. If you have any questions, please contact Customer Service at 715-356-4600.



Tomahawk Live Trap llc.

PO Box 155, Hazelhurst, WI 54531

Web: livetrap.com


Fax: 715-356-4611

Email: trapem@livetrap.com

Like Us On



Tomahawk Live Trap Diagram (figure 1)



Tomahawk Bait Sticks & Paste Baits

Proper baiting is very important for successful trapping. A combination of scent attractant and food bait is the most effective method. Tomahawk scent attracting paste baits are effective year round and hold up under extreme weather conditions. Dip a bait stick into the proper paste bait, and hang the bait stick at the back of the trap so that it dangles at eye level behind the trip pan. Visit our website at www.livetraps.com for our complete selection of paste baits.

Select the appropriate food bait from the chart below. It is important to lead animals into the trap with food bait. Place a small amount of bait just outside and centered in front of the trap, place a small amount inside the trap just in front of the trip pan, and place most of the food bait just behind the trip pan to entice the animal to step on the pan and trigger the trap.

| | |
|---------------------|--|
| Cat or Bobcat | Fish, meats, cat food. |
| Chipmunks | Sunflower seeds, peanut butter, cereal, grains, popcorn. |
| Dogs, Coyotes | Meat, dog food. |
| Fox, Red and Gray | Fish, meat, dog food. |
| Gophers | Peanut butter spread on bread. |
| Groundhog/woodchuck | Apples, Green vegetables, sweet corn, lettuce, peas. |
| Opossum | Vegetables, apples, chicken entrails, canned cat food, almost anything edible will work. |
| Otter | Fish |
| Rabbit | Fresh vegetables, apples. In winter time feed corn works well. |
| Raccoon | Marshmallows, fruit bars, fruit loops. Also raw fish, meat, sweet corn or fruit. |
| Rats, Large | Cheese, peanut butter, grain. |
| Skunk | Apples, fish, hard boiled eggs cut in half. Grape jelly on bread. |
| Snapping Turtle | Chopped fish. |
| Squirrels | Peanut butter, sunflower seeds, field corn, oatmeal grains. |

How to Set Your Tomahawk Single Door Trap



1. Lift the (C) Door Stop. *(Skip step if the product you purchased does not have a safety door stop)



2. To open, insert your index finger through the (B) Door Lift, use your thumb to push the (A) safety door forward against the (D) door panel.



3. Lift Safety Door and Door Panel up.



4. While the doors are in the up position pull the (G-a) trigger loop forward and lower the door so it rests on the (G-b) Trigger Hook



5. Congratulations, you have set your new Tomahawk Live Trap



How to Set your Tomahawk Double Door Trap



1. Lift the rear door stop. *(Skip step if the product you purchased does not have a safety door stop)



2. Lift the entire rear door up until it presses against the underside of the top of the trap



3. Use your free hand to open the front door. this will engage the back door trigger rod which will hold the rear door in place.



4. While the doors are in the up position pull the (G-a) trigger loop forward and lower the door so it rests on the (G-b) Trigger Hook



6. Congratulations, you have set your new Tomahawk Live Trap




How to Set-up Your Tomahawk Collapsible Live Trap



1. Release roll hooks that are holding the trap together



2. Lift handle to open to the trap's working shape (both front and rear doors will automatically fall in place)



3. Secure backdoor by using roll hooks



4. Move U-bar down into position and hold in place with roll hooks.



5. Secure U-bar with roll clips. Now your trap is ready to set. Refer to trap setting instructions on adjacent panel

Trip Pan Height Adjustment

Trip pan height can be raised or lowered to your preference by adjusting the trigger assembly. You will need two pliers to adjust the gap between the hook and loop. *Note: Current settings are at factory specs for optimal use. Any adjustments may hinder the effectiveness of the trap.*



How to Adjust

Adjustment can be made by grabbing the hook and loop with pliers as shown and adjusting the gap between them. Pull the hook and loop forward or backward from front to back of the trap.


front



Note: Do not adjust the gap sideways, from side to side of the trap.


Increase Pan Height

Push the hook toward the rear of the trap while holding the hoop in place to increase the gap.



Decrease Pan Height

Pull the hook toward the front of the trap while holding the hoop in place to decrease the gap.




Heavy/Light Set Adjustments

The trigger assembly can be adjusted for heavier or lighter sets. This may be necessary for different size animals such as juveniles and adults. See *figure 1* for trigger location. *Note: Current settings are at factory specs for optimal use. Any adjustments may hinder the effectiveness of the trap.*




How to Adjust

Adjustment can be made by grabbing the bottom or base of the "L" (hook) with pliers and bending down for light and up for heavy settings.



Light Adjustment

Grab the base of the hook and bend down for a light adjustment



Heavy Adjustment

Grab the base of the hook and bend up for a heavier adjustment.